

Operating instructions

Mini Compact Terminal SCTMb

Note

The Operating instructions were originally written in German. Store in a safe place for future reference. Subject to technical changes without notice. No responsibility is taken for printing or other types of errors.

Published by

© J. Schmalz GmbH, 06/23

This document is protected by copyright. J. Schmalz GmbH retains the rights established thereby. Reproduction of the contents, in full or in part, is only permitted within the limits of the legal provisions of copyright law. Any modifications to or abridgments of the document are prohibited without explicit written agreement from J. Schmalz GmbH.

Contact

J. Schmalz GmbH
Johannes-Schmalz-Str. 1
72293 Glatten, Germany
T: +49 (0) 7443 2403-0
schmalz@schmalz.de
www.schmalz.com

Contact information for Schmalz companies and trade partners worldwide can be found at:
www.schmalz.com/salesnetwork

Contents

1 Important Information	5
1.1 Note on Using this Document	5
1.2 The technical documentation is part of the product	5
1.3 Type Plate	5
1.4 Symbols	6
2 Fundamental Safety Instructions	7
2.1 Intended Use	7
2.2 Non-Intended Use	7
2.3 Personnel Qualification	7
2.4 Warnings in This Document	8
2.5 Modifications to the Product	8
3 Product Description	9
3.1 Mini Compact Terminal Description	9
3.2 Description of the Ejector	9
3.3 Variants and product keys	11
3.4 Components of the Mini Compact Terminal	12
4 Technical Data	13
4.1 General parameters	13
4.2 Electrical Parameters	13
4.3 Mechanical Data	13
5 Blow off modes	16
6 Transportation and Storage	17
6.1 Checking the Delivery	17
6.2 Reusing the Packaging	17
7 Installation	18
7.1 Installation Instructions	18
7.2 Installation	18
7.3 Pneumatic Connection	19
7.4 Connecting the Compressed Air and Vacuum	19
7.5 Optional: External blow-off connection (EB)	20
7.6 Electrical Connection	20
8 Operation	22
8.1 General Preparations	22
9 Help with Malfunctions	23
10 Warranty	24
11 Maintenance	25
11.1 Safety	25
11.2 Replacing the Silencer Insert	25
11.3 Cleaning the Mini Compact Terminal	27

12 Spare and Wearing Parts, Accessories 28

 12.1 Spare and Wearing Parts..... 28

 12.2 Accessories..... 28

13 Decommissioning and Recycling 29

 13.1 Disposing of the Product..... 29

 13.2 Materials Used 29

14 Declarations of Conformity..... 30

 14.1 EU Declaration of Conformity..... 30

 14.2 UKCA Conformity 30

1 Important Information

1.1 Note on Using this Document

J. Schmalz GmbH is generally referred to as Schmalz in this document.

The document contains important notes and information about the different operating phases of the product:

- Transport, storage, start of operations and decommissioning
- Safe operation, required maintenance, rectification of any faults

The document describes the product at the time of delivery by Schmalz and is aimed at:

- Installers who are trained in handling the product and can operate and install it
- Technically trained service personnel performing the maintenance work
- Technically trained persons who work on electrical equipment

1.2 The technical documentation is part of the product

1. For problem-free and safe operation, follow the instructions in the documents.
 2. Keep the technical documentation in close proximity to the product. The documentation must be accessible to personnel at all times.
 3. Pass on the technical documentation to subsequent users.
- ⇒ Failure to follow the instructions in these Operating instructions may result in injuries!
- ⇒ Schmalz is not liable for damage or malfunctions that result from failure to heed these instructions.

If you still have questions after reading the technical documentation, contact Schmalz Service at:

www.schmalz.com/services

1.3 Type Plate



The type plates (1) and (2) are permanently attached to the Terminal and must always be clearly legible.

The type plate (1) contains the following data:

- Designation, incl. individual configuration code (terminal "XY", ejector "AAA")

The type plate (2) contains the following data:

- Part number
- Permitted pressure range
- Manufacturing date
- Serial number
- QR code

Identical individual discs are installed in groups in the terminal as blocks. The following counting method is defined for identification of the ejector blocks:

The ejector block to the right of the type plate (1) is the first ejector block. The second ejector block is assembled next to that one, and so on, up to a maximum of four blocks.

Please specify all the information above when ordering replacement parts, making warranty claims or for any other inquiries.

1.4 Symbols



This symbol indicates useful and important information.

- ✓ This symbol represents a prerequisite that must be met before an action is performed.
- ▶ This symbol represents an action to be performed.
- ⇒ This symbol represents the result of an action.

Actions that consist of more than one step are numbered:

1. First action to be performed.
2. Second action to be performed.

2 Fundamental Safety Instructions

2.1 Intended Use

The mini compact terminal (SCTM) is designed to generate a vacuum for gripping and transporting objects when used in conjunction with suction cups. Depending on the design, the electrical control signals are transmitted directly or via appropriate communication lines.

Neutral gases are approved as evacuation media. Neutral gases include air, nitrogen and inert gases (e.g. argon, xenon and neon). For further information, see (> See ch. Technical Data).

The product is built in accordance with the latest standards of technology and is delivered in a safe operating condition; however, hazards may arise during use.

The product is intended for industrial use.

Intended use includes observing the technical data and the installation and operating instructions in this manual.

2.2 Non-Intended Use

Schmalz accepts no liability for damages caused by non-intended usage of the .

In particular, the following are considered non-intended use:

- Use in potentially explosive atmospheres
- Use in medical applications
- Lifting people or animals
- Evacuation of objects that are in danger of imploding

2.3 Personnel Qualification

Unqualified personnel cannot recognize dangers and are therefore exposed to higher risks!

The operating company must ensure the following points:



- The personnel must be commissioned for the activities described in these operating instructions.
- The staff must be at least 18 years of age and physically and mentally capable.
- The operating staff have been instructed in the operation of the product and have read and understood the operating instructions.
- Installation, maintenance, and repairs must be carried out only by specialists or by persons who can prove that they have undergone appropriate training.

Applicable for Germany:

A qualified employee is defined as an employee who has received technical training and has the knowledge and experience – including knowledge of applicable regulations – necessary to enable him or her to recognize possible dangers and implement the appropriate safety measures while performing tasks. Qualified employees must observe the relevant industry-specific rules and regulations.

2.4 Warnings in This Document

Warnings warn against hazards that may occur when handling the product. The signal word indicates the level of danger.

Signal word	Meaning
 WARNING	Indicates a medium-risk hazard that could result in death or serious injury if not avoided.
 CAUTION	Indicates a low-risk hazard that could result in minor or moderate injury if not avoided.
NOTE	Indicates a danger that leads to property damage.

2.5 Modifications to the Product

Schmalz assumes no liability for consequences of modifications over which it has no control:

1. The product must be operated only in its original condition as delivered.
2. Use only original spare parts from Schmalz.
3. The product must be operated only in perfect condition.

3 Product Description

3.1 Mini Compact Terminal Description



The Schmalz mini compact terminal SCTMb, or SCTMb for short, is a compact unit of multiple vacuum generators known as ejectors. Thanks to its modular design, up to 16 individual ejectors can be controlled and configured independently. It can be used to handle different parts simultaneously and independently using just one vacuum system.

To control the suction and blow-off functions, the SCTMb has a discrete interface for each valve. The compressed air supply can be connected centrally for all ejectors. As an alternative, it can also be connected separately for each ejector.

3.2 Description of the Ejector



3.2.1 Applying Suction to the Workpiece/Part (Vacuum Generation)

The ejector is designed for handling and holding workpieces by means of a vacuum in combination with suction systems. The vacuum is generated in a nozzle according to the venturi principle, using suction generated by the flow of accelerated compressed air. Compressed air is channeled into the ejector and flows through the nozzle. A vacuum is generated immediately downstream of the motive nozzle; this causes the air to be sucked through the vacuum connection. The air and compressed air that have been removed by the suction exit together via the silencer.

The venturi nozzle on the ejector is activated and deactivated using the suction command:

- In the NO (normally open) version, vacuum generation is deactivated when the suction signal is received.
(This means that if the power fails or if no control signal is present, vacuum is constantly generated (continuous suction).)

- In the NC (normally closed) version, vacuum generation is activated when the suction signal is received.
(This means that if the power fails or if no control signal is present, no vacuum is generated.)

When objects with airtight surfaces are picked up, the integrated non-return valve prevents the vacuum from dropping.

Optionally, "Ejector discs" can also be selected with the function "External vacuum (EV)". With that function, the vacuum is supplied externally, and the air is sucked in through the vacuum connection.

3.2.2 Depositing the Workpiece/Part (Blowing Off)

In blow off mode, the vacuum circuit of the ejector is supplied with compressed air. This ensures that the vacuum drops quickly, allowing the workpiece/part to be deposited quickly.

The "Blow off" pilot valve is controlled directly. The ejector switches to blow off mode for as long as the signal is present.

The blow off function can be triggered by the ejector in two ways:

- Externally controlled actuation of the blow off valve
- Optional: external blow off

3.3 Variants and product keys

The item designation of the SCTM is composed of a product key, which indicates the number of ejectors installed and their exact properties.


The SCTM product key (so-called system configuration), e.g. SCTMc-MP-6-XY-2AAF-2AB0-2AAH, is composed as follows:

Feature	Variants	Comment
Product class	SCTM terminal with c-ejectors Basic: b Controlled: c Intelligent: i	—
Terminal type	MP (multipole), [IOL, ECT, EIP, PNT]	MP is only available in the SCTMc variant
Number of ejectors	6	Max. of 16; for SCTMc MP the max. is only 7
Code terminal	XY	Contains all basic functions/properties in coded form
Ejector block 1	2 AAF individual discs	Contains the complete "type information" of the blocked individual discs
Ejector block 2	2 AB0 individual discs	
Ejector block 3	2 AAH individual discs	

Important notes:

- Only unmixed terminals may be constructed (b, c, or i ejectors)
- A maximum of 4 individual discs can be used
- Identical individual discs must be installed grouped together as blocks.
- The combination of the optional functions "External blow-off (EB)" and "External vacuum (EV)" cannot be selected.

3.4 Components of the Mini Compact Terminal



- | | | | |
|----|--|----|---|
| 1 | 4x mounting slots | 2 | 2x end plates |
| 3 | Type plate 1 | 4 | "Suction" solenoid valve |
| 5 | "Blow-off" solenoid valve | 6 | Electrical connection for each solenoid valve |
| 7 | Manual auxiliary actuation for each solenoid valve | 8 | Optional: Compressed air connection interface for each ejector disc |
| 9 | Compressed air connection (feed through both end plates for 9 or more individual discs.) | 10 | Vacuum connection |
| 11 | Optional: Connection for external blow-off EB or external vacuum supply (marking 1A) | 12 | Type plate 2 |
| 13 | Optional: Collective exhaust air connector (marking 3) | 14 | Blow-off valve screw |
| 15 | Silencer (marking 3) | 16 | SCPMtb ejector disc |

4 Technical Data

4.1 General parameters

Parameter	Version	Symbol	Limit value			Comment
			min.	optimal	max.	
Working temperature		T_{amb}	0° C	—	+50° C	—
Storage temperature		T_{sto}	-10° C	—	60° C	—
Humidity		H_{rel}	10% r.h.	—	85% r.h.	Free from condensation
Degree of protection		—	—	—	IP40	—
Operating pressure (flow pressure)	03	P	2 bar	4 bar	6 bar	—
	05	P	4 bar	4 bar	6 bar	—
	07	P	4 bar	4 bar	6 bar	—
	10	P	4 bar	4.5 bar	6 bar	—
	12	P	4 bar	4.5 bar	6 bar	—
Operating medium	Air or neutral gas, filtered to 5 µm, without oil, class 3-3-3 compressed air quality in acc. with ISO 8573-1					

4.2 Electrical Parameters

Supply voltage	DC 24 V ± 10% (PELV ¹⁾)		
Polarity reversal protection	Yes		
Current consumption (at 24 V)	—	Typical current consumption ²⁾	Max. current consumption ²⁾
	SCPMb – xx – NC	50 mA	70 mA
	SCPMb – xx – NO	75 mA	115 mA

¹⁾ The power supply must correspond to the regulations in accordance with EN60204 (protected extra-low voltage).

²⁾ Value for each ejector disc

4.3 Mechanical Data


4.3.1 Performance Data

Type	Nozzle 03	Nozzle 05	Nozzle 07	Nozzle 10	Nozzle 12
Nozzle size [mm]	0.3	0.5	0.7	1.0	1.2
Degree of evacuation [%]	87				92
Max. suction rate [l/min] ¹⁾	2.2	7.5	15	28	30
Air consumption for suction [l/min]	3.5	9	22	45	51
Air consumption for blow off [l/min]	10				
Sound pressure level, unobstructed suction [dB(A)] ¹⁾	51	66	70	71	76
Sound pressure level, suction [dB(A)]	42	55	70	72	75
Pressure range [bar]	2 to 6	4 to 6			

Type	Nozzle 03	Nozzle 05	Nozzle 07	Nozzle 10	Nozzle 12
Rec. diameter of compressed air hose [mm] ²⁾	2			4	
Rec. diameter of vacuum hose [mm] ²⁾	2			4	
Weight [g]	80				

¹⁾ At optimum operating pressure (SCPM...03/05/07: 4 bar; SCPM...10/12: 4,5 bar) ²⁾ For max. length of 2 m
The values specified apply to each ejector. The values for terminals vary according to the number of ejectors installed.

4.3.2 Dimensions



B	B1	B2	B4	d	G1(d1)	G2(d2)	H	H1
79.9	97.8	8.9	42.9	4.5	4	8	59	64.7
H2	H3	H4	L	L1	L2	L3	X1	Y1
31.5	8	8	37.8+(n*12.5)	56.8+(n*12.5)	15	12.5	45.8+(n*12.5)	32.5

All dimensions given in millimeters [mm].

The letter "n" stands for the number of ejector discs installed in the terminal.

The weight of one terminal amounts to:


- approx. 175 g+(n*80) g if it has up to and including 9 ejectors
- approx. 205 g+(n*80) g if it has 10 to 16 ejectors

4.3.3 Pneumatic circuit plans


Key:

NC	Normally closed
NO	Normally open
1	Compressed air connection
2	Vacuum connection
3	Exhaust outlet
1A	"Separate blow off" compressed air connection


NC




NO



NC-EB



NO-EB



5 Blow off modes

5.1 Externally Controlled Blow-Off

The “blow off” valve is controlled directly by the “blow off” command. The ejector switches to blow off mode for as long as the “blow off” signal is present.

The “blow off” signal is given priority over the “suction” signal.

6 Transportation and Storage

6.1 Checking the Delivery

The scope of delivery can be found in the order confirmation. The weights and dimensions are listed in the delivery notes.

1. Compare the entire delivery with the supplied delivery notes to make sure nothing is missing.
2. Damage caused by defective packaging or occurring in transit must be reported immediately to the carrier and J. Schmalz GmbH.

6.2 Reusing the Packaging

The product is delivered in cardboard packaging. The packaging should be reused to safely transport the product at a later stage.



Keep the packaging for future transport or storage.

7 Installation

7.1 Installation Instructions



CAUTION

Improper installation or maintenance

Personal injury or damage to property

- ▶ Prior to installation and before maintenance work, the product must be disconnected from the power supply and secured against unauthorized restart.

For safe installation, the following instructions must be observed:


1. Use only the connectors, mounting holes and attachment materials that have been provided.
2. Firmly connect and secure pneumatic and electrical line connections to the compact terminal.
3. Ensure that there is adequate installation space in the area where the product will be installed.

7.2 Installation


The Terminal may be installed in any position.

The terminal is attached using the mounting slots (4 pieces). There is also the option of mounting DIN rails.

- ▶ The four slots are used to attach them. The terminal must be secured in place using at least 4 M4 screws. The maximum tightening torque is 2 Nm.



- ▶ As an option, the holes can be used to attach DIN rails for mounting.



7.3 Pneumatic Connection



⚠ CAUTION

Compressed air or vacuum in direct contact with the eye

Severe eye injury

- ▶ Wear eye protection
- ▶ Do not look into compressed air openings
- ▶ Do not look into the silencer air stream
- ▶ Do not look into vacuum openings such as suction cups, suction lines and hoses.




⚠ CAUTION

Noise pollution due to incorrect installation of the pressure and vacuum connections

Hearing damage

- ▶ Correct installation.
- ▶ Wear ear protectors.

7.4 Connecting the Compressed Air and Vacuum



- | | |
|---|---|
| 1 | 1x compressed air connection per 9 ejector discs (marking 1) |
| 3 | Optional: 1x compressed air connection per ejector disc (marking 1) |

- | | |
|---|---|
| 2 | 1x vacuum air connection per ejector disc (marking 2) |
|---|---|

The compressed air connector with the plug connector 8/6 or 1/8" thread is marked with the number 1 on the ejector disc.

- ▶ Connect compressed air hose. For threaded connectors, the maximum tightening torque is 1 Nm.

The vacuum connector with the plug connector 8/2 or 6/4 or M5 or M7 thread is marked with the number 2 on the ejector disc.

- ▶ Connect the vacuum hose. For threaded connectors, the maximum tightening torque is 1 Nm.

7.5 Optional: External blow-off connection (EB)

The terminal is also available with an additional compressed air connector for the blow-off function.


With the external blow-off function (EB), the blow-off pulse is controlled separately and independently of the compressed air supply for vacuum generation, allowing you to use a different medium (e.g. nitrogen) for the blow-off function.

It also allows you to precisely set the blow-off pressure using an external pressure regulator (between 2 and 6 bar).

The blow-off flow rate can also be set between 0% and 100% directly on the respective ejector disc. This can be used, for example, to set down small and lightweight workpieces with high positioning precision.

The hose size and the thread on the connector depend on the particular ejector disc and can have the following dimensions:

- Push-in: 8/6
- Thread: 1/8" thread, female



- ▶ Connect the compressed air hose for external blow-off (connector marked with 1A) and adjust the blow-off flow rate using the adjusting screw (2).

7.6 Electrical Connection



NOTE


Incorrect power supply

Destruction of the integrated electronics

- ▶ Operate the product using a power supply unit with protected extra-low voltage (PELV).
- ▶ The system must incorporate safe electrical cut-off of the power supply in compliance with EN60204.
- ▶ Do not connect or disconnect the connector under tension and/or when voltage is applied.

The electrical connection is established directly via the connection plugs of the valves. The connection of the valves is independent of the polarity.

- ✓ Provide connection cable (for example, 2x item no.: 21.04.06.00086)



- ▶ Insert the connection cables into the electrical connections (1 and 2) until they click into place.

8 Operation

8.1 General Preparations



WARNING

Extraction of hazardous media, liquids or bulk material

Personal injury or damage to property!

- ▶ Do not extract harmful media such as dust, oil mists, vapors, aerosols etc.
- ▶ Do not extract aggressive gases or media such as acids, acid fumes, bases, biocides, disinfectants or detergents.
- ▶ Do not extract liquids or bulk materials, e.g. granulates.

Always carry out the following tasks before activating the system:


1. Before each start of operations, ensure that the safety features are in perfect condition and fully functional.
2. Check the device for visible damage and deal with any problems immediately (or notify the supervisor).
3. Ensure that only authorized persons are present in the working area of the machine or system in order to prevent any hazard from switching on the machine.

8.2 Changing the Blow-Off Flow Rate on the Ejector



Do not overwind past the stop on the valve screw. The blow off flow rate can be adjusted within the range between 0% and 100%.

There is a valve screw below the vacuum connection that can be used to adjust the blow-off flow rate. The valve screw is equipped with a stop on both sides.



1. Turn the valve screw clockwise to reduce the flow rate.
2. Turn the valve screw counterclockwise to increase the flow rate.

9 Help with Malfunctions

Fault	Possible cause	Solution
Power supply disrupted	Electrical connection	▶ Make sure device is properly connected to power
Ejector does not respond	No power supply	▶ Check electrical connection
	No compressed air supply	▶ Check the compressed air supply
Vacuum level is not reached or vacuum is built up too slowly	Silencer is dirty	▶ Replace the silencer
	Leakage in hose line	▶ Check hose connections
	Leakage at suction cup	▶ Check suction cup
	Operating pressure too low	▶ Increase operating pressure. Note the maximum limits!
	Internal diameter of hose line too small	▶ Observe recommendations for hose diameter
Load cannot be held	Suction cup too small	▶ Select a larger suction cup
	Vacuum level too low	▶ Increase operating pressure (observe max. permissible limits)

10 Warranty

This system is guaranteed in accordance with our general terms of trade and delivery. The same applies to spare parts, provided that these are original parts supplied by us.

We are not liable for any damage resulting from the use of non-original spare parts or accessories.

The exclusive use of original spare parts is a prerequisite for the proper functioning of the system and for the validity of the warranty.

Wearing parts are not covered by the warranty.

11 Maintenance

11.1 Safety

Maintenance work may only be carried out by qualified personnel.



WARNING

Risk of injury due to incorrect maintenance or troubleshooting

- ▶ Check the proper functioning of the product, especially the safety features, after every maintenance or troubleshooting operation.



CAUTION

Damage due to flying parts

Risk of injury or damage to property!

- ▶ Wear eye protection
- ▶ Before performing maintenance, make sure that the vacuum and compressed air system is at atmospheric pressure.



NOTE

Improper maintenance

Damage to the mini compact terminal and the ejector discs!

- ▶ Switch off the supply voltage before performing any maintenance.
- ▶ Secure it so that it cannot be switched back on.
- ▶ Operate the terminal only with a silencer or with the collective exhaust air connected.


11.2 Replacing the Silencer Insert

Heavy infiltration of dust, oil, and so on, may contaminate the silencer insert and reduce the suction capacity. Cleaning the silencer insert is not recommended due to the capillary effect of the porous material.


If the suction capacity decreases, replace the silencer insert:

- ✓ Deactivate the ejector and depressurize the pneumatic systems.


1. Place a small flat screwdriver on the ejector as shown and loosen the clamp.



2. Remove the clamp.




3. Then remove the silencer and silencer insert from the ejector.



4. Pull the silencer insert out of the housing and dispose of it.




5. Insert the new silencer insert into the housing and reinstall the silencer.



6. Mount the clamp in the correct position.

- ⇒ The clamp is mounted flush with the underside of the ejector and the clamp legs both lie in the grooves. It does not protrude from the ejector.



7. Check that the silencer is held tightly by pulling on the housing (hand-tight).

11.3 Cleaning the Mini Compact Terminal

1. For cleaning, do not use aggressive cleaning agents such as industrial alcohol, white spirit or thinners. Only use cleaning agents with pH 7–12.
2. Remove dirt on the exterior of the device with a soft cloth and soap suds at a maximum temperature of 60° C. Make sure that the product is not soaked in soapy water.
3. Ensure that no moisture gets into the electrical connection.

12 Spare and Wearing Parts, Accessories

12.1 Spare and Wearing Parts

Maintenance work may only be carried out by qualified personnel.



⚠ WARNING

Risk of injury due to incorrect maintenance or troubleshooting

- ▶ Check the proper functioning of the product, especially the safety features, after every maintenance or troubleshooting operation.

The following list contains the most important spare and wearing parts.

Designation	Part no.	Type
Silencer insert	10.02.02.05403	Wearing part
NO ejector suction valve for nozzle size 03	10.05.01.00396	Spare part
NO ejector suction valve for nozzle size 05/07/10/12	10.05.01.00395	Spare part
NC ejector suction valve for nozzle size 03	10.05.01.00395	Spare part
NC ejector suction valve for nozzle size 05/07/10/12	10.05.01.00396	Spare part
Blow off valve (NC valve)	10.05.01.00395	Spare part
Ejector wearing part, VST SCPMi/c/b	10.02.02.06536	Wearing part
Ejector wearing part, VST SCPMi/c/b-EV	10.02.02.06537	Wearing part

When tightening the fastening screws on the valves, observe the maximum tightening torque of 0.1 Nm.

12.2 Accessories

Designation	Part no.	Note
Connection cable, ASK B-MIC10 3000 K-2P	21.04.06.00086	Connector 1: Vent Micro10 mm connector; Cable length: 3000 mm; Connector 2: Cable, 2-pin; Material: PUR cable
Plug-in screw union M5	10.08.02.00468	—
Plug-in screw union M7	10.08.02.00469	—
DIN rail mounting kit	10.02.02.05804	—

13 Decommissioning and Recycling

13.1 Disposing of the Product

Recover the disassembled parts for recycling or reuse (provided no agreement on return or disposal has been made).

1. Dispose of the product properly after replacement or decommissioning.
2. Observe the country-specific guidelines and legal obligations for waste prevention and disposal.

13.2 Materials Used

Component	Material
Housing	PA6-GF
Inner components	Aluminum alloy, anodized aluminum alloy, stainless steel, POM
Silencer insert	Porous PE
Screws and brackets	Galvanized steel
Sealing	Nitrile rubber (NBR)
Lubrication	Silicone-free

14 Declarations of Conformity

14.1 EU Declaration of Conformity

The manufacturer Schmalz confirms that the product Terminal described in these operating instructions fulfills the following applicable EU directives:

2006/42/EC	Machinery Directive
2014/30/EU	Electromagnetic Compatibility
2011/65/EU	Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment

The following harmonized standards were applied:

EN ISO 12100	Safety of machinery — General principles for design — Risk assessment and risk reduction
EN 61000-6-2+AC	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
EN 61000-6-3+A1+AC	Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments
EN 50581	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances



The EU Declaration of Conformity valid at the time of product delivery is delivered with product or made available online. The standards and directives cited here reflect the status at the time of publication of the operating and assembly instructions.

14.2 UKCA Conformity

The manufacturer Schmalz confirms that the product described in these operating instructions fulfills the following applicable UK regulations:

2008	Supply of Machinery (Safety) Regulations
2016	Electromagnetic Compatibility Regulations
2012	The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations

The following designated standards were applied:

EN ISO 12100	Safety of machinery — General principles for design — Risk assessment and risk reduction
EN 61000-6-2+AC	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
EN 61000-6-3+A1+AC	Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments
EN 50581	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances



The Declaration of Conformity (UKCA) valid at the time of product delivery is delivered with the product or made available online. The standards and directives cited here reflect the status at the time of publication of the operating and assembly instructions.

At Your Service Worldwide



Vacuum automation

WWW.SCHMALZ.COM/AUTOMATION

Handling systems

WWW.SCHMALZ.COM/EN-US/VACUUM-LIFTERS-AND-CRANE-SYSTEMS

J. Schmalz GmbH
Johannes-Schmalz-Str. 1
72293 Glatten, Germany
T: +49 (0) 7443 2403-0
schmalz@schmalz.de
WWW.SCHMALZ.COM